




DIGITAL NETWORK CONTROL (6X62/6X72/6Y82/6Y91)



2011/8/22



NEWS NO.	DATE	COMMENT
PE0-OM-110008	Mar.,31,2011	MOD:FIG.39 MULTI DISPLAY ASSY REVISION
PE0-OM-110033	Aug.,20,2011	MOD:FIG.16,17,19,20,22,23,24,26,27,30 REVISION

DIGITAL NETWORK CONTROL PARTS CATALOGUE

©2010 by Yamaha Motor Co., Ltd.
1st edition, September 2010
All rights reserved.

Any reprinting or unauthorized use without the written permission of Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

 Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.

It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

"UR" Use specified parts number.

"UN" Use as many as needed.

"AP" Alternate Parts

"LM" Locally Made (Parts need to be ordered locally)

"F#" Frame No. (Applicable machine No.)

"O/S" Over Size

- 3. The number of components for assembly
 - Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
 - The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5-83310-60	FRONT FLASHER LIGHT ASSY	2	
115-83311-60	.BULB (6V-18W)	1	

4. Applicable colours of graphics are represented in the "REMARKS" as shown below.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4-24110-00-X5	FUEL TANK COMP.	2	MXR
3J1-24240-10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.


6. The asterisk (*) before a reference number indicates modified items after the first edition.


FOREWORD


REMOTE CONTROL SPECIFICATION LIST (TYPE:6X6/6X7)

			ME	CHANICAL	SPECIFICA	ATION				
PART NO.	LIST UP SEC.	TYPE CODE	SERIAL NO.		ENG	GINE		SINGLE	DUAL S	TATION
PARTINO.	FIG.NO.	TIPE CODE	SERIAL NO.	SINGLE	TWIN	TRIPLE	QUAD	STATION	MAIN	SUB
6X6-48205-30		Α	6X6:0003236-	0	*	*	*	0	*	*
6X6-48205-40	1,2,9	С	6X6:1001104-	0	*	*	*	0	0	*
6X6-48205-50]	G	6X6:3000143-	0	*	*	*	*	*	0
6X6-48207-30		В	6X6:0503218-	*	0	*	*	0	*	*
6X6-48207-40	3,4,10	D	6X6:1501366-	*	0	*	*	0	0	*
6X6-48207-50]	Н	6X6:3500335-	*	0	*	*	*	*	0
6X6-48208-40	5,6,11	F	6X6:2500557-	*	*	0	*	0	0	
6X6-48208-50	3,0,11	К	6X6:5000122-	*	*	0	*	*	*	0
6X6-48209-00	7,12,13	L	6X6:5500000-	*	*	*	0	0	0	
6X6-48209-10] ',12,13	M	6X6:6000000-	*	*	*	0	*	*	0
6X7-48206-10	8,14	Α	6X7:0000749-	0	*	*	*	0	*	*

SERIAL NO.







CONTENTS

LAYOUT CHART 1 (SINGLE)1
LAYOUT CHART 2 (SINGLE)2
LAYOUT CHART 3 (TWIN)3
LAYOUT CHART 4 (TWIN)4
LAYOUT CHART 5 (TRIPLE)5
LAYOUT CHART 6 (TRIPLE)6
LAYOUT CHART 7 (QUAD)7
LAYOUT CHART 8 (6X7)8
DBW REMOTE CONTROL 1 (SINGLE)9
DBW REMOTE CONTROL 2 (TWIN)12
DBW REMOTE CONTROL 3 (TRIPLE)16
DBW REMOTE CONTROL 4 (QUAD)20
DBW REMOTE CONTROL 5 (QUAD)23
DBW REMOTE CONTROL 6 (6X7)24
SWITCH & PANEL 1 (SINGLE)27
SWITCH & PANEL 2 (SINGLE)28
SWITCH & PANEL 3 (SINGLE)29
SWITCH & PANEL 4 (TWIN)30
SWITCH & PANEL 5 (TWIN)31
SWITCH & PANEL 6 (TWIN)32
SWITCH & PANEL 7 (TRIPLE)33
SWITCH & PANEL 8 (TRIPLE)34
SWITCH & PANEL 9 (TRIPLE)35
SWITCH & PANEL 1036
SWITCH & PANEL 11 (QUAD)37
SWITCH & PANEL 12 (QUAD)38
SWITCH & PANEL 13 (QUAD)40
SWITCH & PANEL 14 (6X7)41
ELECTRICAL WIRE HARNESS42
OPTIONAL PARTS 144
OPTIONAL PARTS 245
DIGITAL NETWORK GAUGE 146
DIGITAL NETWORK GAUGE 247
DIGITAL NETWORK GAUGE 349
DIGITAL NETWORK GAUGE 450
DIGITAL NETWORK GAUGE 551
DIGITAL NETWORK GAUGE 652
DIGITAL NETWORK GAUGE 753
COMMAND LINK PLUS54

INDEX

NUMERICAL INDEX		55
-----------------	--	----

OLD COMBINATION (SINGLE)




FIG. 1 LAYOUT CHART 1 (SINGLE)

REF.	PART NO.	DESCRIPTION	DNC	REMARKS
1	6X6-48205-30	REMOTE CONTROL ASSY (SINGLE)	1	NOT FOR SALE
	6X6-48205-40	REMOTE CONTROL ASSY (SINGLE)	1	NOT FOR SALE
	6X6-48205-50	REMOTE CONTROL ASSY (SINGLE)	1	NOT FOR SALE
2	6R5-82570-05	PANEL SWITCH ASSY	1	1 & 2 STATION MAIN
3	6X6-82570-80	PANEL SWITCH ASSY	1	2 STATION SUB
4	6X6-82570-90	PANEL SWITCH ASSY	- ₁ - -	2 STATION SUB
5	6X6-82570-B0	PANEL SWITCH ASSY	2	2 STATION MAIN & SUB
			- -	-
			_ _ _ - -	- -
			- -	-

1




FIG. 2 LAYOUT CHART 2 (SINGLE)

REF.							
NO.	PART NO.	DESCRIPTION	DNC	REMARKS			
1	6X6-48205-30	REMOTE CONTROL ASSY (SINGLE)	1	NOT FOR SALE			
	6X6-48205-40	REMOTE CONTROL ASSY (SINGLE)	1	NOT FOR SALE			
	6X6-48205-50	REMOTE CONTROL ASSY (SINGLE)	1	NOT FOR SALE			
2	6X6-82570-30	PANEL SWITCH ASSY	1	1 & 2 STATION MAIN			
3	6X6-82570-80	PANEL SWITCH ASSY	1	2 STATION SUB			
- - 4	6X6-82570-90	PANEL SWITCH ASSY	- 1 -	2 STATION SUB			
5	6X6-82570-B0	PANEL SWITCH ASSY	2	2 STATION MAIN & SUE			
				- -			
			-	-			
			- - - -	- -			

OLD COMBINATION (TWIN)




FIG. 3 LAYOUT CHART 3 (TWIN)

REF.	PART NO.	DESCRIPTION	DNC	REMARKS
1	6X6-48207-30	REMOTE CONTROL ASSY (TWIN)	1	NOT FOR SALE
	6X6-48207-40	REMOTE CONTROL ASSY (TWIN)	1	NOT FOR SALE
	6X6-48207-50	REMOTE CONTROL ASSY (TWIN)	1	NOT FOR SALE
2	6Y8-82570-02	PANEL SW., TWIN	1	1 & 2 STATION MAIN
3	6X6-82570-E0	PANEL SWITCH ASSY	1	2 STATION SUB
4	6X6-82570-90	PANEL SWITCH ASSY		2 STATION SUB
5	6X6-82570-B0	PANEL SWITCH ASSY	2	2 STATION MAIN & SUB
				- -
			_ _ _ _	- -
				-





FIG. 4 LAYOUT CHART 4 (TWIN)

REF NO.	PART NO.	DESCRIPTION	DNC		REMARKS
1	6X6-48207-30	REMOTE CONTROL ASSY (TWIN)	1		NOT FOR SALE
	6X6-48207-40	REMOTE CONTROL ASSY (TWIN)	1		NOT FOR SALE
	6X6-48207-50	REMOTE CONTROL ASSY (TWIN)	1		NOT FOR SALE
2	6X6-82570-40	PANEL SWITCH ASSY	1		1 & 2 STATION MAIN
3	6X6-82570-60	PANEL SWITCH ASSY	1		1 & 2 STATION MAIN
4	6X6-82570-E0	PANEL SWITCH ASSY		- +	2 STATION SUB
5	6X6-82570-90	PANEL SWITCH ASSY	1		2 STATION SUB
6	6X6-82570-B0	PANEL SWITCH ASSY	2		2 STATION MAIN & SUB
				- +	
				- -	
				- +	

OLD COMBINATION (TRIPLE)




6X62100-J050

FIG. 5 LAYOUT CHART 5 (TRIPLE)

	id. 5 EATOST SHART S(TIM EE)							
REF NO.		DESCRIPTION	9	DNC			REMARKS	
1	6X6-48208-40	REMOTE CONTROL ASSY (TRIPLE)		1			NOT FOR SALE	
	6X6-48208-50	REMOTE CONTROL ASSY (TRIPLE)		1			NOT FOR SALE	
2	6X5-82570-01	PANEL SWITCH ASSY		1			1 & 2 STATION MAIN	
3	6X6-82570-F0	PANEL SWITCH ASSY		1			2 STATION SUB	
4	6X6-82570-90	PANEL SWITCH ASSY		1			2 STATION SUB	
- - 5	6X6-82570-B0	PANEL SWITCH ASSY		2	- -	- † –	2 STATION MAIN & SUB	
				†-		- † -		
				†-		- † -		
				1-		† -		
				7-		T -		
			ı ı				·	

NEW COMBINATION (TRIPLE) Command Link Plus




6X62100-J060

FIG. 6 LAYOUT CHART 6 (TRIPLE)

Dee Control Charles (Time EL)								T
REF NO.		DESCRIPTION		DNC				REMARKS
1	6X6-48208-40	REMOTE CONTROL ASSY (TRIPLE)		1				NOT FOR SALE
	6X6-48208-50	REMOTE CONTROL ASSY (TRIPLE)		1				NOT FOR SALE
2	6X6-82570-50	PANEL SWITCH ASSY		1				1 & 2 STATION MAIN
3	6X6-82570-70	PANEL SWITCH ASSY		1				1 & 2 STATION MAIN
4	6X6-82570-F0	PANEL SWITCH ASSY		1				2 STATION SUB
5	6X6-82570-90	PANEL SWITCH ASSY		1	- -	-	† –	2 STATION SUB
6	6X6-82570-B0	PANEL SWITCH ASSY		2				2 STATION MAIN & SUB
						- -	ļ _	
					-	-	t –	
						- -	 	
						7	T	

NEW COMBINATION (QUAD) Command Link Plus




6X62100-J070

FIG. 7 LAYOUT CHART 7 (QUAD)

FIG. 7 LATOOT CHART 7 (GOAD)						
REF NO.	PART NO.	DESCRIPTION	DNC	REMARKS		
1	6X6-48209-00	REMOTE CONTROL ASSY (QUAD)	1	NOT FOR SALE		
	6X6-48209-10	REMOTE CONTROL ASSY (QUAD)	1	NOT FOR SALE		
2	6X6-82570-R0	PANEL SWITCH ASSY (FOR PORT)	1	1 & 2 STATION MAIN		
3	6X6-82570-S0	PANEL SWITCH ASSY (FOR C-PORT)	1	1 & 2 STATION MAIN		
4	6X6-82570-T0	PANEL SWITCH ASSY (FOR C-STBD)	1	1 & 2 STATION MAIN		
5	6X6-82570-U0	PANEL SWITCH ASSY (FOR STBD)	- - - -	1 & 2 STATION MAIN		
6	6X6-82570-V0	PANEL SWITCH ASSY	2	2 STATION MAIN & SUB		
7	6X6-82570-J0	PANEL SWITCH ASSY (PORT-P/CP)	1	2 STATION SUB		
8	6X6-82570-K0	PANEL SWITCH ASSY (STBD-CS/S)	1	2 STATION SUB		
9	6X6-82570-L0	PANEL SWITCH ASSY	2	2 STATION MAIN & SUB		
		. – – – – – – – – – – – – – – – – – – –				

7



6X62100-J080

FIG. 8 LAYOUT CHART 8 (6X7)

0.	DESCRIPTION	DNC	REMARKS
1 6X7-48206-10	REMOTE CONTROL ASSY	1	NOT FOR SALE
2 64D-82570-20	PANEL SWITCH ASSY	1	
	. – – – – – – – – – – – – – – –		




FIG. 9 DBW REMOTE CONTROL 1 (SINGLE)

REF	PART NO.	DESCRIPTION	DNC	REMARKS
1	6X6-48205-30	REMOTE CONTROL ASSY (SINGLE)	1	NOT FOR SALE
	6X6-48205-40	REMOTE CONTROL ASSY (SINGLE)	1	NOT FOR SALE
	6X6-48205-50	REMOTE CONTROL ASSY (SINGLE)	1	NOT FOR SALE
2	6X6-82563-00	.TRIM & TILT SWITCH ASSY	1	
3	6X6-48221-00	.LEVER, CONTROL	1	
4	6X6-48222-00	.GRIP, CONTROL LEVER	- 1 -	-
5	6X6-48224-00	.COVER, CONTROL LEVER	1	
6	6X6-48224-10	.COVER, CONTROL LEVER	1	
7	98580-05014	.SCREW, PAN HEAD	6	
8	92990-05300	.WASHER, INTERNAL TOOTH	1	
9	6X6-48171-00	BOLT		-
10	92990-08600	.WASHER, PLATE	1	
11	EL8-48127-00	.SCREW 1	4	
12	6X6-48119-04	.COVER	1	
13	6X6-48215-30	GRAPHIC	1	
14	6X6-48216-00	GRAPHIC	- 1 -	-
15	6X6-84301-00	.PILOT LIGHT ASSY 1	1	
16	6X6-48167-00	.PLUG	1	
17	6X6-48167-50	.PLUG	1	
18	6X6-48219-00	.COVER, LEAD	1	
19	6X6-8259E-00	.SWITCH ASSY	- 1 - -	-
20	92990-05200	.WASHER, PLAIN	5	
21	6X6-48176-00	.GROMMET	1	
22	98580-04010	.SCREW, PAN HEAD	3	
23	92D80-05016	BOLT, SOCKET HEAD	2	
24	6X6-481A0-01	.REMO-CON. CASE ASSY		- -
25	6X6-48212-00	.BACK PLATE 1	1	




FIG. 9 DBW REMOTE CONTROL 1 (SINGLE)

REF		DECORPTION	,	0				DEMARKO
NO.	PART NO.	DESCRIPTION		DNC				REMARKS
	6X6-48144-10	.PLATE, STOPPER 2		1				
27	6X6-48242-01	.SHAFT, DRIVE		1				
28	6X6-48233-01	.GEAR 2		1				
29	6X6-48238-00	.SPRING, DETENT		1				
30	6X6-48237-00	.ADAPTOR		1				
31	6X6-48236-00	.ROLLER, DETENT		1		_	† -	
32	6X6-48189-00	.RETAINER		1				
33	703–48198–00	.WASHER, WAVE		1				
34	6X6-48193-00	.WASHER 3		1				
35	6X6-48118-00	.CLIP, SHIFT LEVER		1				
36	6X6-48234-00	.BUSHING 1		- ₋		-	 	
37	6X6-48267-00	BOLT SET		1				
38	6X6-48158-00	.SPRING 1		1				
39	6X6-48264-00	.FRICTION, THROTTLE		1				
40	704–48287–00	.WASHER		5				
41	6X6-81145-00			- ₁		-	 	
42	98780-05014	.SCREW, FLAT HEAD		4				
43	6X6-48213-00	.BACK PLATE 2		1				
44	6X6-48228-00	.HOLDER, SWITCH		1				
45	6X6-85590-20	.CONTROL UNIT ASSY		1				
- <u>-</u>	 703–82591–00	 .BAND		- ₋	- -	-	 	
47	97780–50145	.SCREW, TAPPING		4				UR
	98580-05060	.SCREW, PAN HEAD		4				UR
48	95380-05600	.NUT		4				
49	6X6-82590-G0	.WIRE HARNESS ASSY		1				FOR 6X6-48205-30
	 6X6–82590–A0		. – – – – –	 1	- -	- -	 	FOR 6X6-48205-40
	6X6-82590-D0	.WIRE HARNESS ASSY		1				FOR 6X6-48205-50
	57.0 02000-D0	ILL I I/I INLOG AGG I		ľ				1 011 0/10 70200-00
							1	




FIG. 9 DBW REMOTE CONTROL 1 (SINGLE)

52 6X6-82582-40CAP 1 (4P) 1 FOR 6X6-82590-A		FIG. 9 DBW REMOTE CONTROL I (SINGLE)							
51 6X6-82582-60CAP 1 (6P)		PART NO.		DNC				REMARKS	
52 6X6-82582-40CAP 1 (4P) 1 FOR 6X6-82590-Ai 53 6X6-82582-B0CAP 1 (12P) 1 FOR 6X6-82590-Ai 54 6X6-48144-00PLATE, STOPPER 2 1 55 6X6-48129-00SCREW 3	50 6	X6-82585-20	CAP 2 (2P)	1					
53 6X6-82582-B0CAP 1 (12P)	51 6>	X6-82582-60	CAP 1 (6P)	1				FOR 6X6-82590-A0	
54 6X6-48144-00 .PLATE, STOPPER 2 1 55 6X6-48129-00 .SCREW 3 2 56 6X6-44191-00 .INDICATOR, SHIFT 1 57 6X6-48176-50 .GROMMET 1 58 6X6-48176-60 .GROMMET 1 59 6X6-48127-00 .SCREW 1 3 60 6X6-48128-00 .SCREW 2 2 61 6X6-81146-00 .SCREW 2 2 62 704-81950-10 .RELAY ASSY 1 63 6X6-82540-00 .NEUTRAL SWITCH ASSY 1 64 6X6-48241-00 .ARM, DRIVE 1 65 6X6-48245-01 .PLATE, LOCK 1 66 6X6-82545-00 .GROMMET 1	52 6	X6-82582-40	CAP 1 (4P)	1				FOR 6X6-82590-A0	
55 6X6-48129-00	53 6>	X6-82582-B0	CAP 1 (12P)	1				FOR 6X6-82590-A0	
56 6X6-44191-00 .INDICATOR, SHIFT 1 57 6X6-48176-50 .GROMMET 1 58 6X6-48176-60 .GROMMET 1 59 6X6-48127-00 .SCREW 1 3 60 6X6-48128-00 .SCREW 2 2 61 6X6-81146-00 .SCREW 2 2 62 704-81950-10 .RELAY ASSY 1 63 6X6-82540-00 .NEUTRAL SWITCH ASSY 1 64 6X6-48241-00 .ARM, DRIVE 1 65 6X6-48245-01 .PLATE, LOCK 1 66 6X6-82545-00 .GROMMET 1	54 6>	X6-48144-00	.PLATE, STOPPER 2	1					
57 6X6-48176-50	55 6>	X6-48129-00	SCREW 3	2	- -		-		
58 6X6-48176-60 .GROMMET 1 59 6X6-48127-00 .SCREW 1 3 60 6X6-48128-00 .SCREW 2 2 61 6X6-81146-00 .SCREW 2 2 62 704-81950-10 .RELAY ASSY 1 63 6X6-82540-00 .NEUTRAL SWITCH ASSY 1 64 6X6-48241-00 .ARM, DRIVE 1 65 6X6-48245-01 .PLATE, LOCK 1 66 6X6-82545-00 .GROMMET 1	56 6>	X6-44191-00	.INDICATOR, SHIFT	1					
59 6X6-48127-00 .SCREW 1	57 6>	X6-48176-50	.GROMMET	1					
60 6X6-48128-00	58 6>	X6-48176-60	.GROMMET	1					
61 6X6-81146-00 .SCREW 2 2 2 62 704-81950-10 .RELAY ASSY 1 1 63 6X6-82540-00 .NEUTRAL SWITCH ASSY 1 1 65 6X6-48241-00 .ARM, DRIVE 1 1 65 6X6-48245-01 .PLATE, LOCK 1 1 66 6X6-82545-00 .GROMMET 1	59 6>	X6-48127-00	.SCREW 1	3					
62 704-81950-10 .RELAY ASSY 1 63 6X6-82540-00 .NEUTRAL SWITCH ASSY 1 64 6X6-48241-00 .ARM, DRIVE 1 65 6X6-48245-01 .PLATE, LOCK 1 66 6X6-82545-00 .GROMMET 1	60 62	X6-48128-00	.SCREW 2	2	- -		-		
63 6X6-82540-00 .NEUTRAL SWITCH ASSY 1 64 6X6-48241-00 .ARM, DRIVE 1 65 6X6-48245-01 .PLATE, LOCK 1 66 6X6-82545-00 .GROMMET 1	61 62	X6-81146-00	.SCREW 2	2					
64 6X6–48241–00 .ARM, DRIVE 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	62 70	04–81950–10	.RELAY ASSY	1					
65 6X6-48245-01 .PLATE, LOCK 1 1 1 66 6X6-82545-00 .GROMMET 1	63 6>	X6-82540-00	.NEUTRAL SWITCH ASSY	1					
66 6X6-82545-00 .GROMMET 1	64 62	X6-48241-00	.ARM, DRIVE	1					
	65 6	X6-48245-01	PLATE, LOCK	1	- -				
67 6X6-8252V-00 .SCREW, SPECIAL 2	66 6>	X6-82545-00	.GROMMET	1					
	67 6X	X6-8252V-00	.SCREW, SPECIAL	2					
					- -				
					- -		-		




FIG. 10 DBW REMOTE CONTROL 2 (TWIN)

REF	DADTNO	DECODIDEION		DEMARKS
NO.	PART NO.	DESCRIPTION	DNC	REMARKS
1	6X6-48207-30	REMOTE CONTROL ASSY (TWIN)	1	NOT FOR SALE
	6X6-48207-40	REMOTE CONTROL ASSY (TWIN)	1	NOT FOR SALE
	6X6-48207-50	REMOTE CONTROL ASSY (TWIN)	1	NOT FOR SALE
2	6X6-82563-00	.TRIM & TILT SWITCH ASSY	1	
3	6X6-48221-00	.LEVER, CONTROL	2	
4	6X6-48222-00	.GRIP, CONTROL LEVER		+-
5	6X6-48224-00	.COVER, CONTROL LEVER	2	
6	6X6-48222-10	.GRIP, CONTROL LEVER	1	
7	6X6-48224-10	.COVER, CONTROL LEVER	2	
8	98580-05014	.SCREW, PAN HEAD	12	
9	92990-05300	.WASHER, INTERNAL TOOTH		+-
10	6X6-48171-00	.BOLT	2	
11	92990-08600	.WASHER, PLATE	2	
12	EL8-48127-00	.SCREW 1	6	
13	6X6-48119-10	.COVER	1	
14	6X6-84301-13	.PILOT LIGHT ASSY 1		+-
15	6X6-48215-40	GRAPHIC	1	
16	6X6-48216-10	GRAPHIC	1	
17	6X6-48167-10	.PLUG	1	
18	6X6-48167-20	.PLUG	1	
19	6X6-48167-60	.PLUG		+-
20	6X6-48219-10	.COVER, LEAD	1	
21	6X6-48219-20	.COVER, LEAD	1	
22	6X6-8259E-00	.SWITCH ASSY	1	
23	92990-05200	.WASHER, PLAIN	10	
24	6X6-48176-10	.GROMMET		
25	6X6-48225-00	.COVER	1	




FIG. 10 DBW REMOTE CONTROL 2 (TWIN)

REF NO.	PART NO.	DESCRIPTION	DNC			R	EMARKS
26	6X6-82563-40	.TRIM & TILT SWITCH ASSY	1				_
27	98580-04010	.SCREW, PAN HEAD	9				
28	92D80-05016	.BOLT, SOCKET HEAD	2				
29	6X6-481A0-01	.REMO-CON. CASE ASSY	1				
30	6X6-48212-00	.BACK PLATE 1	2				
31	6X6-48144-10	.PLATE, STOPPER 2	2	- -	-		
32	6X6-48242-01	.SHAFT, DRIVE	1				
33	6X6-48242-11	.SHAFT, DRIVE	1				
34	6X6-48233-01	.GEAR 2	2				
35	6X6-48238-00	.SPRING, DETENT	2				
36	6X6-48237-00	.ADAPTOR	2	- -			
37	6X6-48236-00	.ROLLER, DETENT	2				
38	6X6-48189-00	.RETAINER	2				
39	703–48198–00	.WASHER, WAVE	2				
40	6X6-48193-00	.WASHER 3	2				
41	6X6-48118-00	.CLIP, SHIFT LEVER	2	- -	-		
42	6X6-48234-00	.BUSHING 1	2				
43	6X6-48267-00	.BOLT SET	2				
44	6X6-48158-00	.SPRING 1	2				
45	6X6-48264-00	.FRICTION, THROTTLE	2				
46	704–48287–00		6	- -	-		
47	98580-05025	.SCREW, PAN HEAD	2				
48	704–48156–00	.NUT 1	1				
49	704-48283-00	.SCREW	1				
50	98780-05014	.SCREW, FLAT HEAD	4				
51	6X6-48213-00	.BACK PLATE 2	2	- -	-		
52	6X6-48228-00	.HOLDER, SWITCH	2				




FIG. 10 DBW REMOTE CONTROL 2 (TWIN)

REF						
NO.	PART NO.	DESCRIPTION	DNC			REMARKS
53	6X6-85590-20	.CONTROL UNIT ASSY	2			
54	703–82591–00	.BAND	8			
55	97780-50145	.SCREW, TAPPING	4			UR
	98580-05060	.SCREW, PAN HEAD	4			UR
56	95380-05600	.NUT	4			
57	6X6-82590-H0	.WIRE HARNESS ASSY	1	- -	- †	FOR 6X6-48207-30
	6X6-82590-B0	.WIRE HARNESS ASSY	1			FOR 6X6-48207-40
	6X6-82590-E0	.WIRE HARNESS ASSY	1			FOR 6X6-48207-50
58	6X6-82585-20	CAP 2 (2P)	2			
59	6X6-82582-60	CAP 1 (6P)	2			FOR 6X6-82590-B0
60	6X6-82582-40	CAP 1 (4P)	2	. – – –	- †	FOR 6X6-82590-B0
61	6X6-82582-B0	CAP 1 (12P)	2			FOR 6X6-82590-B0
62	6X6-48129-00	.SCREW 3	4			
63	6X6-44191-00	.INDICATOR, SHIFT	2			
64	6X6-48176-50	.GROMMET	1			
65	6X6-48176-60	GROMMET	1	- -	- †	-
66	6X6-48127-00	.SCREW 1	6			
67	6X6-48128-00	.SCREW 2	4			
68	6X6-81146-00	.SCREW 2	4			
69	6X6-81145-00	.SCREW 1	2			
70	6X6-82563-50	TRIM & TILT SWITCH ASSY	1	- -	- †	-
71	6X6-481A0-21	.REMO-CON. CASE ASSY	1			
72	704-81950-10	RELAY ASSY	2			
73	6X6-82540-00	.NEUTRAL SWITCH ASSY	1			
74	6X6-48241-00	.ARM, DRIVE	2			
75	6X6-48245-01	.PLATE, LOCK	2	- -	-	-
76	6X6-82545-00	.GROMMET	2			




FIG. 10 DBW REMOTE CONTROL 2 (TWIN)

REF. NO.	PART NO.	DESCRIPTION	DNC		REMARKS
77 6	X6-8252V-00	.SCREW, SPECIAL	4		
78 6	X6–82540–10	.NEUTRAL SWITCH ASSY	1		

FIG. 11 DBW REMOTE CONTROL 3 (TRIPLE)

REF NO.	PART NO.	DESCRIPTION	DNC		REMARKS
1	6X6-48208-40	REMOTE CONTROL ASSY (TRIPLE)	1		NOT FOR SALE
	6X6-48208-50	REMOTE CONTROL ASSY (TRIPLE)	1		NOT FOR SALE
2	6X6-82563-00	.TRIM & TILT SWITCH ASSY	1		
3	6X6-48221-00	.LEVER, CONTROL	2		
4	6X6-48222-00	.GRIP, CONTROL LEVER	2		
5	6X6-48224-00	.COVER, CONTROL LEVER	2	- -	+-
6	6X6-48222-10	.GRIP, CONTROL LEVER	1		
7	6X6-48224-10	.COVER, CONTROL LEVER	2		
8	98580-05014	.SCREW, PAN HEAD	20		
9	92990-05300	.WASHER, INTERNAL TOOTH	2		
10	6X6-48171-00	.BOLT	2	- - -	+-
11	92990-08600	.WASHER, PLATE	2		
12	EL8-48127-00	.SCREW 1	6		
13	6X6-48119-10	.COVER	1		
14	6X6-84301-23	.PILOT LIGHT ASSY 1	1		
15	6X6-48215-50	GRAPHIC		- - -	+-
16	6X6-48216-20	GRAPHIC	1		
17	6X6-48167-10	.PLUG	1		
18	6X6-48167-20	.PLUG	1		
19	6X6-48167-60	.PLUG	2		
20	6X6-48219-10	.COVER, LEAD		- -	+-
21	6X6-48219-20	.COVER, LEAD	1		
22	6X6-8259E-00	.SWITCH ASSY	1		
23	92990-05200	.WASHER, PLAIN	12		
24	6X6-48176-10	.GROMMET	1		
25	6X6-48225-00	.COVER		- - -	+-
26	6X6-82563-40	.TRIM & TILT SWITCH ASSY	1		

FIG. 11 DBW REMOTE CONTROL 3 (TRIPLE)

			,				
REF NO.	PART NO.	DESCRIPTION		DNC			REMARKS
27	98580-04010	.SCREW, PAN HEAD		11			
28	92D80-05016	.BOLT, SOCKET HEAD		2			
29	6X6-481A0-11	.REMO-CON. CASE ASSY		1			
30	6X6-48212-00	.BACK PLATE 1		2			
31	6X6-48144-10	.PLATE, STOPPER 2		2			
32	6X6-48242-01	.SHAFT, DRIVE		1		† -	
33	6X6-48242-11	.SHAFT, DRIVE		1			
34	6X6-48233-01	.GEAR 2		4			
35	6X6-48238-00	.SPRING, DETENT		2			
36	6X6-48237-00	.ADAPTOR		2			
37	6X6-48236-00	ROLLER, DETENT		2		† -	
38	6X6-48189-00	.RETAINER		2			
39	703–48198–00	.WASHER, WAVE		2			
40	6X6-48193-00	.WASHER 3		2			
41	6X6-48118-00	.CLIP, SHIFT LEVER		2			
42	6X6-48234-00	.BUSHING 1		2		+ -	
43	6X6-48267-00	.BOLT SET		2			
44	6X6-48158-00	.SPRING 1		2			
45	6X6-48264-00	.FRICTION, THROTTLE		2			
46	704–48287–00	.WASHER		6			
47	98580-05025	.SCREW, PAN HEAD		4		 	
48	704–48156–00	.NUT 1		1			
49	704–48283–00	.SCREW		1			
50	98780-05014	.SCREW, FLAT HEAD		4			
51	6X6-48213-00	.BACK PLATE 2		2			
- <u>-</u> 52	6X6-48228-00	.HOLDER, SWITCH	-	2	-	+-	
53	6X6-85590-20	.CONTROL UNIT ASSY		3			

FIG. 11 DBW REMOTE CONTROL 3 (TRIPLE)

DEE			-, 	1			
REF NO.	PART NO.	DESCRIPTION		DNC			REMARKS
54	703-82591-00	.BAND		10			
55	97780-50145	.SCREW, TAPPING		4			UR
	98580-05060	.SCREW, PAN HEAD		4			UR
56	95380-05600	.NUT		4			
57	6X6-82590-C0	.WIRE HARNESS ASSY		1			FOR 6X6-48208-40
	6X6-82590-F0	.WIRE HARNESS ASSY		1	- -	 † –	FOR 6X6-48208-50
58	6X6-82585-20	CAP 2 (2P)		3			
59	6X6-82582-60	CAP 1 (6P)		3			FOR 6X6-82590-C0
60	6X6-82582-40	CAP 1 (4P)		3			FOR 6X6-82590-C0
61	6X6-82582-B0	CAP 1 (12P)		3			FOR 6X6-82590-C0
62	6X6-48129-00	.SCREW 3		4	- -	 	
63	6X6-44191-00	.INDICATOR, SHIFT		2			
64	6X6-48176-50	.GROMMET		1			
65	6X6-48176-60	.GROMMET		1			
66	6X6-48127-00	.SCREW 1		8			
67	6X6-48128-00	.SCREW 2		4	- -	 	
68	6X6-81146-00	.SCREW 2		4			
69	6X6-81145-00	.SCREW 1		2			
70	6X6-82563-50	.TRIM & TILT SWITCH ASSY		1			
71	6X6-82563-60	.TRIM & TILT SWITCH ASSY		1			
72	6X6-8259F-10	SWITCH ASSY		1	- -	 	
73	6X6-481A0-31	.REMO-CON. CASE ASSY		1			
74	98780-05010	.SCREW, FLAT HEAD		2			
75	6X6-48211-10	.HOUSING,1		1			
76	6X6-85557-00	.HOLDER		2			
- <u>-</u>	6X6-82591-00	.BAND		2	- -	 	
78	6X6-8252S-00	.SPACER, 1		2			

FIG. 11 DBW REMOTE CONTROL 3 (TRIPLE)

1 10	. II DOWNLIN	OTE CONTROL 3 (TRIPLE)				
REF NO.	PART NO.	DESCRIPTION	DNC			REMARKS
79	6X6-82584-00	.CLAMP	1			
80	6X6-82581-00	.STAY, CORD CLAMP	2			
81	6X7-48127-00	.SCREW 1	1			
82	6X0-48128-00	.SCREW(M6X30)	4			
83	704–81950–10	.RELAY ASSY	4			
84	6X6-82540-00	NEUTRAL SWITCH ASSY	1	- -		
85	6X6-48241-00	.ARM, DRIVE	2			
86	6X6-48245-01	.PLATE, LOCK	2			
87	6X6-82545-00	.GROMMET	2			
88	6X6-8252V-00	.SCREW, SPECIAL	4			
89	6X6-82540-10	.NEUTRAL SWITCH ASSY	1	-	-	
				-	-	
				- -		
			 	_	-	




FIG. 12 DBW REMOTE CONTROL 4 (QUAD)

REF.	PART NO.	DESCRIPTION	DNC	REMARKS
1	6X6-48209-00	REMOTE CONTROL ASSY (QUAD)	1	NOT FOR SALE
	6X6-48209-10	REMOTE CONTROL ASSY (QUAD)	1	NOT FOR SALE
2	6X6-82563-00	TRIM & TILT SWITCH ASSY	1	
3	6X6-48221-00	LEVER, CONTROL	2	
4	6X6-48222-00	GRIP, CONTROL LEVER	2	
5	6X6-48224-00	COVER, CONTROL LEVER	- 2 - -	
6	6X6-48222-10	GRIP, CONTROL LEVER	1	
7	6X6-48224-10	COVER, CONTROL LEVER	2	
8	98580-05014	SCREW, PAN HEAD	28	
9	92990-05300	WASHER, INTERNAL TOOTH	2	
10	6X6-48171-00	BOLT	- 2 - - -	+-
11	92990-08600	WASHER, PLATE	2	
12	EL8-48127-00	SCREW 1	6	
13	6X6-48119-10	COVER	1	
14	6X6-84301-30	PILOT LIGHT ASSY 1	1	
15	6X6-48215-70	.GRAPHIC		+-
16	6X6-48216-10	.GRAPHIC	1	
17	6X6-48167-10	PLUG	1	
18	6X6-48167-20	PLUG	1	
19	6X6-48167-60	PLUG	2	
20	6X6-48219-10	COVER, LEAD	-1 - -	
21	6X6-48219-20	COVER, LEAD	1	
22	6X6-8259E-00	SWITCH ASSY	1	
23	92990-05200	WASHER, PLAIN	14	
24	6X6-48176-10	GROMMET	1	
25	6X6-48225-00	COVER	-1 - -	+-
26	98580-04010	SCREW, PAN HEAD	5	




FIG. 12 DBW REMOTE CONTROL 4 (QUAD)

						
REF NO.	PART NO.	DESCRIPTION	DNC			REMARKS
27	92D80-05016	BOLT, SOCKET HEAD	2			
28	6X6-481A0-11	REMO-CON. CASE ASSY	1			
29	6X6-48212-00	BACK PLATE 1	2			
30	6X6-48144-10	PLATE, STOPPER 2	2			
31	6X6-48242-01	SHAFT, DRIVE	1			
32	6X6-48242-11	SHAFT, DRIVE	1	-	- † -	
33	6X6-48233-01	GEAR 2	4			
34	6X6-48238-00	SPRING, DETENT	2			
35	6X6-48237-00	ADAPTOR	2			
36	6X6-48236-00	ROLLER, DETENT	2			
37	6X6-48189-00	RETAINER	2	- -	- + -	-
38	703–48198–00	WASHER, WAVE	2			
39	6X6-48193-00	WASHER 3	2			
40	6X6-48118-00	CLIP, SHIFT LEVER	2			
41	6X6-48234-00	BUSHING 1	2			
42	6X6-48267-00	BOLT SET	2	- -	-	
43	6X6-48158-00	SPRING 1	2			
44	6X6-48264-00	FRICTION, THROTTLE	2			
45	704–48287–00	WASHER	6			
46	98580-05025	SCREW, PAN HEAD	6			
47	704–48156–00	NUT 1	1	- -	-	
48	704–48283–00	SCREW	1			
49	98780-05014	SCREW, FLAT HEAD	4			
50	6X6-48213-00	BACK PLATE 2	2			
51	6X6-48228-00	HOLDER, SWITCH	2			
- <u>-</u> 52	6X6-85590-20	CONTROL UNIT ASSY	4	-	-	-
53	703–82591–00	BAND	12			







FIG. 12 DBW REMOTE CONTROL 4 (QUAD)

REF NO.	PART NO.	DESCRIPTION	DNC	REMARKS
54	97780–50145	SCREW, TAPPING	4	UR
	98580-05060	SCREW, PAN HEAD	4	UR
55	95380-05600	NUT	4	
56	6X6-48129-00	SCREW 3	4	
57	6X6-44191-00	INDICATOR, SHIFT	2	
58	6X6-48176-50	GROMMET		+-
59	6X6-48176-60	GROMMET	1	
60	6X6-48127-00	SCREW 1	10	
61	6X6-48128-00	SCREW 2	4	
62	6X6-81146-00	SCREW 2	4	
63	6X6-81145-00	SCREW 1		+-
64	6X6-481A0-31	REMO-CON. CASE ASSY	1	
65	6X6-48211-10	HOUSING,1	2	
66	6X6-85557-00	HOLDER	4	
67	6X6-82591-00	BAND	4	
68	6X6-8252S-00	SPACER, 1		+-
69	6X6-82584-00	CLAMP	2	
70	6X6-82581-00	STAY, CORD CLAMP	4	
71	6X7-48127-00	SCREW 1	2	
72	6X0-48128-00	SCREW(M6X30)	8	
73	704–81950–10	RELAY ASSY		+-
74	6X6-82540-00	NEUTRAL SWITCH ASSY	1	
75	6X6-48241-00	ARM, DRIVE	2	
76	6X6-48245-01	PLATE, LOCK	2	
77	6X6-82545-00	GROMMET	2	
- - 78	6X6-8252V-00	SCREW, SPECIAL		+
79	6X6-82540-10	NEUTRAL SWITCH ASSY	1	







6X62100-J130

FIG. 13 DBW REMOTE CONTROL 5 (QUAD)

REF NO.		DESCRIPTION	DNC				REMARKS
1	6X6-82590-J0	WIRE HARNESS ASSY	1				FOR 6X6-48209-00
	6X6-82590-L0	WIRE HARNESS ASSY	1				FOR 6X6-48209-10
2	6X6-82585-20	.CAP 2 (2P)	2				
3	6X6-82582-60	.CAP 1 (6P)	2				FOR 6X6-82590-J0
4	6X6-82582-40	.CAP 1 (4P)	2				FOR 6X6-82590-J0
5	6X6-82582-B0	.CAP 1 (12P)	 2	-	-	 	FOR 6X6-82590-J0
6	6X6-82590-K0	WIRE HARNESS ASSY	1				FOR 6X6-48209-00
	6X6-82590-M0	WIRE HARNESS ASSY	1				FOR 6X6-48209-10
7	6X6-82585-20	.CAP 2 (2P)	2				
8	6X6-82582-60	.CAP 1 (6P)	2				FOR 6X6-82590-K0
9	6X6-82582-40	.CAP 1 (4P)	 2	-		 	FOR 6X6-82590-K0
10	6X6-82582-B0	.CAP 1 (12P)	2				FOR 6X6-82590-K0
11	6X6-82570-N0	PANEL SWITCH ASSY	1				




FIG. 14 DBW REMOTE CONTROL 6 (6X7)

1 10	. IT DOWNER	MOTE CONTROL 6 (6X7)		
REF NO.	PART NO.	DESCRIPTION	DNC	REMARKS
1	6X7-48206-10	REMOTE CONTROL ASSY	1	NOT FOR SALE
2	6X7-82563-00	.TRIM & TILT SWITCH ASSY	1	
3	6X7-48221-00	.LEVER, CONTROL	1	
4	6X7-48222-00	.GRIP, CONTROL LEVER	1	
5	6X7-48224-00	.COVER, CONTROL LEVER	1	
6	6X7-48223-00	LOCK, NEUTRAL		
7	6X7-48224-10	.COVER, CONTROL LEVER	1	
8	703–48227–00	.SPRING, NEUTRAL LOCK	1	
9	6X6-48171-00	.BOLT	1	
10	92990-08600	.WASHER, PLATE	1	
11	6X6-48128-00	.SCREW 2		
12	6X7-48119-00	.COVER	1	
13	6X7-48167-10	.PLUG	1	
14	6X7-48167-00	.PLUG	1	
15	6X7-48225-00	.COVER	1	
16	6X7-44191-00	.INDICATOR, SHIFT	· - ₁ - -	
17	6X7-48215-10	.GRAPHIC	1	
18	6X7-481A0-01	.REMO-CON. CASE ASSY	1	
19	6X7-48212-00	.BACK PLATE 1	1	
20	6X7-48189-00	.RETAINER	1	
21	6X7-8259E-00	.SWITCH ASSY	· - ₁ -	
22	6X7-84301-00	.PILOT LIGHT ASSY 1	1	
23	6X7-48233-00	.GEAR 2	1	
24	6X7-48242-00	.SHAFT, DRIVE	1	
25	6X7-48228-00	.HOLDER, SWITCH	1	
<u>26</u>	6X7-82545-00	.GROMMET	· - ₁ - - -	
27	6X6-82540-00	.NEUTRAL SWITCH ASSY	1	




FIG. 14 DBW REMOTE CONTROL 6 (6X7)

	d. 14 BBW NEWOTE CONTINUE CONT.)								
REF NO.	PART NO.	DESCRIPTION	DNC	REMARKS					
28	6X6-48245-01	.PLATE, LOCK	1						
29	6X6-48241-00	.ARM, DRIVE	1						
30	6X6-48264-00	.FRICTION, THROTTLE	1						
31	6X6-48267-00	.BOLT SET	1						
32	704–48287–00	.WASHER	1						
33	6X6-48158-00	.SPRING 1							
34	6X6-48236-00	ROLLER, DETENT	1						
35	6X6-48237-00	.ADAPTOR	1						
36	6X6-48238-00	.SPRING, DETENT	1						
37	6X6-48234-00	.BUSHING 1	1						
38	703–48198–00	.WASHER, WAVE		-					
39	6X6-48193-00	.WASHER 3	1						
40	6X6-48118-00	.CLIP, SHIFT LEVER	1						
41	703-82591-00	.BAND	4						
42	6X6-8252V-00	.SCREW, SPECIAL	2						
43	6X7-48127-00	.SCREW 1		-					
44	EL8-48127-00	.SCREW 1	8						
45	6X7-82575-00	ENGINE STOP SWITCH ASSY	1						
46	6X7-82590-40	.WIRE HARNESS ASSY	1						
47	6X6-82585-20	CAP 2 (2P)	1						
48	6X6-82582-A0	CAP 1 (3P)		-					
49	6X6-82585-60	CAP 2 (6P)	1						
50	6X6-82585-40	CAP 2 (4P)	1						
51	6X7-82590-20	.WIRE HARNESS ASSY	1						
52	6X6-85590-20	.CONTROL UNIT ASSY	1						
53	704–81950–10	. RELAY ASSY		-					
54	6X6-48211-10	.HOUSING,1	1						




FIG. 14 DBW REMOTE CONTROL 6 (6X7)

FIG	. 14 DOW KEI	OTE CONTROL 6 (6X7)					
REF NO.	PART NO.	DESCRIPTION	DNC				REMARKS
55	6X6-85557-00	HOLDER	2				
56	6X6-82591-00	.BAND	1				
57	6X6-8252S-00	.SPACER, 1	2				
58	6X6-82584-00	.CLAMP	1				
59	6X6-82581-00	.STAY, CORD CLAMP	2				
60	6X0-48128-00	.SCREW(M6X30)	4	-		-	
61	98580-05025	.SCREW, PAN HEAD	2				
62	98580-05014	.SCREW, PAN HEAD	8				
63	92990-05200	.WASHER, PLAIN	2				
64	98780-06035	.SCREW, FLAT HEAD	3				UR
	97780–06230	.SCREW, TAPPING	3	-		-	UR
65	6X0-48156-00	.NUT 1	3				
66	701–48287–00	.WASHER	3				
67	6X7-48128-00	.SCREW 2	1				
68	6X7-48176-10	.GROMMET	1				
				- -	-		
				- -	-		
				- -	-	_	

OLD SWITCH PANEL (SINGLE: 1 & 2 STATION-MAIN)






FIG. 15 SWITCH & PANEL 1 (SINGLE)

_	a. 13 SWITCH	A FANEL I (SINGLE)					
REI NO.	DADT NA	DESCRIPTION	DNC				REMARKS
1	6R5-82570-05	PANEL SWITCH ASSY	1				1 & 2 STATION MAIN
2	704-82571-02	.PANEL, SWITCH	1				
3	6R5-82588-01	PLATE	1				
4	6R5-82510-02	.MAIN SWITCH ASSY	1				
5	676-82577-00	CAP, KEY	1				
6	688–82575–01	ENGINE STOP SWITCH ASSY	1	-	 		
7	682-82556-00	LANYARD, STOP SWITCH	1				
8	64D-82581-00	.STAY, CORD CLAMP	1				
9	97303-05012	.BOLT	1				
10	92903-05100	.WASHER, SPRING	1				
11	95303-05700		1	-	 	-	
12	6R5-83383-00	.BUZZER	1				
				-	 		
				_	 	_	
				1 -	 	_	

NEW SWITCH PANEL (SINGLE: 1 & 2 STATION-MAIN)






FIG. 16 SWITCH & PANEL 2 (SINGLE)

	. 10 0111101110	FANEL 2 (SINGLE)					
REF NO.		DESCRIPTION	DNC				REMARKS
1	6X6-82570-30	PANEL SWITCH ASSY	-				1 & 2 STATION MAIN
2	6X6-82510-00	.MAIN SWITCH ASSY		I			
3	688-82575-01	.ENGINE STOP SWITCH ASSY	-	ı			
4	682-82556-00	LANYARD, STOP SWITCH		ı			
5	703-83383-A0	.BUZZER	-	ı			
- <u>-</u>	6X6-82571-00	PANEL, SWITCH	-	- 1	 -		
			- -		 - +		
				1-	 -	_	
			- -	-	 - +		
				1_	_		

NEW SWITCH PANEL (SINGLE : 2 STATION-SUB)







FIG. 17 SWITCH & PANEL 3 (SINGLE)

		X PANEL 3 (SINGLE)			1		
REF NO.	PART NO.	DESCRIPTION	DNC				REMARKS
1	6X6-82570-80	PANEL SWITCH ASSY	1				2 STATION SUB
2	6X6-8259E-20	.SWITCH ASSY	1				
3	703-83383-A0	.BUZZER	1				
4	6X6-82716-20	.CORD SWITCH	1				
5	6X6-82571-40	.PANEL, SWITCH	1				
			 	 			
_			 	1-[-			
_			 	l_L.	l		
_			 	 	-		
-			 	 		-	
					1		

OLD SWITCH PANEL (TWIN: 1 & 2 STATION-MAIN)








FIG. 18 SWITCH & PANEL 4 (TWIN)

110	FIG. 10 SWITCH & FANEL 4 (TWIN)									
REF NO.		DESCRIPTION	S	DNC				REMARKS		
1	6Y8-82570-02	PANEL SW., TWIN		1				1 & 2 STATION MAIN		
2	6Y8-82571-01	.PLATE, PANEL SWITCH		1						
3	6Y8-82510-02	.MAIN SWITCH ASSY		2						
4	676-82577-00	CAP, KEY		1						
5	6K1-82575-00	.ENGINE STOP SWITCH ASSY		1						
6	682-82556-00	LANYARD, STOP SWITCH		1	- -		-			
7	6R5-83383-00	.BUZZER		2						
8	68V-81950-00	.RELAY ASSY		2						
9	6Y8-82507-00	LEAD, IGNITION SWITCH RELAY		1						
10	64D-82581-00	.STAY, CORD CLAMP		2						
11	97303–05012	.BOLT		2	-		-			
12	92903-05100	.WASHER, SPRING		2						
13	95303-05700	.NUT		2						
14	6X6-8258A-L0	EXTENSION, WIRE HARNESS		2						
				+	-		-			
				+	-					
			-	4	- -		-			
						<u> </u>	<u> </u>			

NEW SWITCH PANEL (TWIN : 1 & 2 STATION-MAIN) 6X62100J1901

FIG. 19 SWITCH & PANEL 5 (TWIN)

FIG. 19 SWITCH & PANEL 5 (TWIN)								
REF NO.		DESCRIPTION		DNC				REMARKS
1	6X6-82570-40	PANEL SWITCH ASSY		1				1 & 2 STATION MAIN
2	6X6-82510-10	.MAIN SWITCH ASSY		1				
3	6X6-82575-10	ENGINE STOP SWITCH ASSY		1				
4	682-82556-00	LANYARD, STOP SWITCH		1				
5	703–83383–A0	.BUZZER		1				
- - 6	6X6-81980-00	.DIODE ASSY		1	-	1-	 	
7	6X6-82570-60	PANEL SWITCH ASSY		1				1 & 2 STATION MAIN
8	6X6-8259E-20	.SWITCH ASSY		2				
9	6X6-82716-00	.CORD SWITCH		1				
10	6X6-82571-10	.PANEL, SWITCH		1				
- - 11	6X6-82571-20	.PANEL, SWITCH		1	-	1-	-	
					.		_	
					-	-	-	
					-	- -	 	
							1	<u> </u>

NEW SWITCH PANEL (TWIN : 2 STATION-SUB)




FIG. 20 SWITCH & PANEL 6 (TWIN)

		a i Aite o (i wiit)		1				
REF. NO.	PART NO.	DESCRIPTION		DNC				REMARKS
1 62	X6-82570-E0	PANEL SWITCH ASSY		1				2 STATION SUB
2 6	X6-8259E-20	.SWITCH ASSY		2				
3 70	03-83383-A0	.BUZZER		1				
4 62	X6-82716-40	.CORD SWITCH		1				
5 62	X6-81980-00	.DIODE ASSY		1				
6 6	X6-82571-20	. PANEL, SWITCH	 	- ₋	- -			
			 		_ -			
			 	- +	-			
			 	_	_	-	L _	

OLD SWITCH PANEL (TRIPLE : 1 & 2 STATION-MAIN)




FIG. 21 SWITCH & PANEL 7 (TRIPLE)

REF. NO.	PART NO.	DESCRIPTION	C				REMARKS
1	6X5-82570-01	PANEL SWITCH ASSY		1			1 & 2 STATION MAIN
2	6X5-82510-01	.MAIN SWITCH ASSY	;	3			
3	676-82577-00	CAP, KEY		1			
4	6X5-82575-00	.ENGINE STOP SWITCH ASSY		1			
5	682-82556-00	LANYARD, STOP SWITCH		1			
6	6X5-82571-00	.PANEL, SWITCH		1 -		- † -	-
7	6X5-83383-00	.BUZZER		2			
8	6X5-82581-00	.STAY, CORD CLAMP		1			
9	6X4-83383-00	.BUZZER		1			
10	6X5-82507-00	.WIRE, LEAD		1			
11	68V-81950-00	.RELAY ASSY		3		- † -	-
12	6X6-8258A-L0	EXTENSION, WIRE HARNESS	;	3			
					.	_	
				-		_	_

NEW SWITCH PANEL (TRIPLE :1 & 2 STATION-MAIN)




FIG. 22 SWITCH & PANEL 8 (TRIPLE)

REF NO.	PART NO.	DESCRIPTION	S					REMARKS
1	6X6-82570-50	PANEL SWITCH ASSY		1				1 & 2 STATION MAIN
2	6X6-82510-20	.MAIN SWITCH ASSY		1				
3	6X6-82575-10	ENGINE STOP SWITCH ASSY		1				
4	682-82556-00	LANYARD, STOP SWITCH		1				
5	703-83383-A0	.BUZZER		1				
6	6X6-81980-00	.DIODE ASSY	-	1	-	-	-	
7	6X6-82570-70	PANEL SWITCH ASSY		1				1 & 2 STATION MAIN
8	6X6-8259E-20	.SWITCH ASSY		3				
9	6X6-82716-10	.CORD SWITCH		1				
10	6X6-82571-10	.PANEL, SWITCH		1				
11	6X6-82571-30	.PANEL, SWITCH	-,	1	-	- +		
				1.	_	_		
				Ī				
			-	+	-	- †	-	
			l .			-		

NEW SWITCH PANEL (TRIPLE : 2 STATION-SUB)






FIG. 23 SWITCH & PANEL 9 (TRIPLE)

REF. NO. PART NO.	DESCRIPTION		DNC			REMARKS
1 6X6-82570-F0	PANEL SWITCH ASSY		1			2 STATION SUB
2 6X6-8259E-20	.SWITCH ASSY		3			
3 703-83383-A0	.BUZZER		1			
4 6X6-82716-50	.CORD SWITCH		1			
5 6X6-81980-00	.DIODE ASSY		1			
6 6X6-82571-30	.PANEL, SWITCH		1	- -	 	
		-			 	
		-			 	
				_	 	

NEW SWITCH PANEL (SINGLE / TWIN / TRIPLE-2 STATION)




FIG. 24 SWITCH & PANEL 10

REF. NO.	PART NO.	DESCRIPTION	DNC			REMARKS
1	6X6-82570-90	PANEL SWITCH ASSY	1			2 STATION SUB
2	6X6-82570-B0	PANEL SWITCH ASSY	2	!		2 STATION MAIN & SUB
3	6X6-81980-10	.DIODE ASSY	1			
4	6X6-82571-50	.PANEL, SWITCH	1			
5	682-82556-00	.LANYARD, STOP SWITCH	1			
6	6X6-82571-70	.PANEL, SWITCH	-	1		
				 	-	
				1_		
				1- -	-	
			-	 	-	-
						<u> </u>




FIG. 25 SWITCH & PANEL 11 (QUAD)

. 10	. 23 34110110	X PANEL II (QUAD)		
REF NO.	PART NO.	DESCRIPTION	DNC	REMARKS
1	6X6-82570-R0	PANEL SWITCH ASSY (FOR PORT)	1	1 & 2 STATION MAIN
2	64D-82571-00	.PANEL, SWITCH	1	
3	64D-82588-00	.PLATE	1	
4	64D-82510-20	.MAIN SWITCH ASSY	1	
5	703-82577-00	CAP, KEY	1	
6	6K1-82532-00	CAP		
7	64D-82581-00	.STAY, CORD CLAMP	1	
8	97095-05012	.BOLT	1	
9	92903-05100	.WASHER, SPRING	1	
10	95303-05700	.NUT	1	
11	688–83383–11	.BUZZER		† -
12	6X6-82507-00	.WIRE, LEAD	1	
13	68V-81950-00	.RELAY ASSY	1	
14	6X6-82570-S0	PANEL SWITCH ASSY (FOR C-PORT)	1	1 & 2 STATION MAIN
15	64D-82571-00	.PANEL, SWITCH	1	
16	64D-82588-00	.PLATE		
17	64D-82510-20	.MAIN SWITCH ASSY	1	
18	703-82577-00	CAP, KEY	1	
19	6K1-82532-00	CAP	1	
20	64D-82581-00	.STAY, CORD CLAMP	1	
21	97095–05012	BOLT		
22	92903-05100	.WASHER, SPRING	1	
23	95303-05700	.NUT	1	
24	688-83383-11	.BUZZER	1	
25	6X6-82507-10	.WIRE, LEAD	1	
26	68V-81950-00	.RELAY ASSY		




FIG. 26 SWITCH & PANEL 12 (QUAD)

REF	PART NO.	DESCRIPTION	C				REMARKS
10.	6X6-82570-T0	PANEL SWITCH ASSY (FOR C-STBD)	ON CO	_			1 & 2 STATION MAIN
							1 & 2 STATION MAIN
	64D-82571-00	.PANEL, SWITCH					
		.PLATE	-				
4	64D-82510-20	.MAIN SWITCH ASSY	-				
5	703–82577–00	CAP, KEY					
6	6K1-82532-00	CAP				ĪĪ	
7	64D-82581-00	.STAY, CORD CLAMP	-				
8	97095–05012	.BOLT	-				
9	92903-05100	.WASHER, SPRING	-				
10	95303-05700	.NUT	-				
11	688–83383–11	.BUZZER	-	-		†-	
12	6X6-82507-20	.WIRE, LEAD	-				
13	68V-81950-00	.RELAY ASSY	-				
14	6X6-82570-U0	PANEL SWITCH ASSY (FOR STBD)					1 & 2 STATION MAIN
15	64D-82571-00	.PANEL, SWITCH	-				
16	64D-82588-00	.PLATE		-		+-	
17	64D-82510-20	.MAIN SWITCH ASSY	-				
18	703-82577-00	CAP, KEY	-				
19	6K1-82532-00	CAP	-				
20	64D-82581-00	.STAY, CORD CLAMP	-				
<u>-</u> 21	97095–05012			-	-	+-	
22	92903-05100	.WASHER, SPRING	-				
23	95303-05700	.NUT	-				
	688-83383-11	.BUZZER					
	6X6-82507-30	.WIRE, LEAD					
_	68V-81950-00	RELAY ASSY		⊥ _		<u> </u>	
							O CTATIONI MAIN' ® CL
21	6X6-82570-V0	PANEL SWITCH ASSY	-				2 STATION MAIN & SU




FIG. 26 SWITCH & PANEL 12 (QUAD)

REF NO.	PART NO.	DESCRIPTION	C	DINC			REMARKS
28	6X6-82575-30	.ENGINE STOP SWITCH ASSY		2			
29	6X6-82556-00	.LANYARD, STOP SWITCH		1			
30	6X6-82570-L0	PANEL SWITCH ASSY		1			2 STATION MAIN & SUB
31	6X6-8258A-L0	EXTENSION, WIRE HARNESS	.	4			
32	6X6-8258A-U0	EXTENSION, WIRE HARNESS	:	2			
33	6X6-82571-50	.PANEL, SWITCH		2	-	 -	
34	6X6-82571-70	.PANEL, SWITCH	1	1			
				1	_	 -	
				1		 	
				+	-	 _	
					_		

NEW SWITCH PANEL (QUAD : 2 STATION-SUB) 15,16 6X62100J2701

FIG. 27 SWITCH & PANEL 13 (QUAD)

FIG	FIG. 27 SWITCH & PANEL 13 (QUAD)								
REF NO.	PART NO.	DESCRIPTION	DNC		REMARKS				
1	6X6-82570-J0	PANEL SWITCH ASSY (PORT-P/CP)	1		2 STATION SUB				
2	6X6-8259E-20	.SWITCH ASSY	2						
3	703-83383-A0	.BUZZER	1						
4	6X6-82716-40	.CORD SWITCH	1						
5	6X6-81980-00	.DIODE ASSY	1						
6	6X6-82570-K0	PANEL SWITCH ASSY (STBD-CS/S)	-1		2 STATION SUB				
7	6X6-8259E-20	.SWITCH ASSY	2						
8	703–83383–A0	.BUZZER	1						
9	6X6-82716-40	.CORD SWITCH	1						
10	6X6-81980-00	.DIODE ASSY	1						
11	6X6-82570-V0	PANEL SWITCH ASSY			2 STATION MAIN & SUB				
12	6X6-82575-30	.ENGINE STOP SWITCH ASSY	2						
13	6X6-82556-00	.LANYARD, STOP SWITCH	1						
14	6X6-82570-L0	PANEL SWITCH ASSY	1		2 STATION MAIN & SUB				
15	6X6-82571-80	.PANEL, SWITCH	1						
16	6X6-82571-90	.PANEL, SWITCH	-						
17	6X6-82571-50	.PANEL, SWITCH	2						
18	6X6-82571-70	.PANEL, SWITCH	1						
			-	- -					

SWITCH PANEL (6X7)








FIG. 28 SWITCH & PANEL 14 (6X7)


REF NO.	DA DT NIC	DESCRIPTION	DNC				REI	//ARK	s	
	64D-82570-20	PANEL SWITCH ASSY	1							
2	64D-82571-00	.PANEL, SWITCH	1							
3	64D-82588-00	.PLATE	1							
4	64D-82510-20	.MAIN SWITCH ASSY	1							
5	703–82577–00	CAP, KEY	1							
6	6K1-82532-00		1	-		 -				· –
7	64D-82581-00	.STAY, CORD CLAMP	1							
8	97303-05012	.BOLT	1							
9	92903-05100	.WASHER, SPRING	1							
10	95303-05700	.NUT	1							
11	 688–83383–11	BUZZER	_ ₁	-		 -				· –
				-	L _	 _				
				-	-	 				· –

DIGITAL ELECTRONIC REMOTE CONTROL WIRE HARNESS



Uses to connect between main helm RC and 2nd hlem RC.
(For new digital electronic RC)






Uses to connect between main helm RC and 2nd hlem RC. (Quad RC special)

6X62100-J290


FIG. 29 ELECTRICAL WIRE HARNESS


1 10	i. 23 ELLCTRI	CAL WINE HANNESS		
REF NO.	PART NO.	DESCRIPTION	DNC	REMARKS
1	6X6-8258A-00	EXTENSION, WIRE HARNESS (6.1M)	1	UR FOR SINGLE
	6X6-8258A-00	EXTENSION, WIRE HARNESS (6.1M)	2	UR FOR TWIN
	6X6-8258A-00	EXTENSION, WIRE HARNESS (6.1M)	3	UR FOR TRIPLE
	6X6-8258A-00	EXTENSION, WIRE HARNESS (6.1M)	4	UR FOR QUAD
	6X6-8258A-10	EXTENSION, WIRE HARNESS (7M)	1	UR FOR SINGLE
	6X6-8258A-10	EXTENSION, WIRE HARNESS (7M)	2	UR FOR TWIN
	6X6-8258A-10	EXTENSION, WIRE HARNESS (7M)	3	UR FOR TRIPLE
	6X6-8258A-10	EXTENSION, WIRE HARNESS (7M)	4	UR FOR QUAD
	6X6-8258A-20	EXTENSION, WIRE HARNESS (8M)	1	UR FOR SINGLE
	6X6-8258A-20	EXTENSION, WIRE HARNESS (8M)	2	UR FOR TWIN
	6X6-8258A-20	EXTENSION, WIRE HARNESS (8M)	3	UR FOR TRIPLE
	6X6-8258A-20	EXTENSION, WIRE HARNESS (8M)	4	UR FOR QUAD
	6X6-8258A-30	EXTENSION, WIRE HARNESS (10M)	1	UR FOR SINGLE
	6X6-8258A-30	EXTENSION, WIRE HARNESS (10M)	2	UR FOR TWIN
	6X6-8258A-30	EXTENSION, WIRE HARNESS (10M)	3	UR FOR TRIPLE
	6X6-8258A-30	EXTENSION, WIRE HARNESS (10M)		UR FOR QUAD
	6X6-8258A-40	EXTENSION, WIRE HARNESS (12M)	1	UR FOR SINGLE
	6X6-8258A-40	EXTENSION, WIRE HARNESS (12M)	2	UR FOR TWIN
	6X6-8258A-40	EXTENSION, WIRE HARNESS (12M)	3	UR FOR TRIPLE
	6X6-8258A-40	EXTENSION, WIRE HARNESS (12M)	4	UR FOR QUAD
2	6X6-8258A-G0	EXTENSION, WIRE HARNESS (5M)		UR FOR SINGLE
	6X6-8258A-G0	EXTENSION, WIRE HARNESS (5M)	2	UR FOR TWIN
	6X6-8258A-G0	EXTENSION, WIRE HARNESS (5M)	3	UR FOR TRIPLE
	6X6-8258A-G0	EXTENSION, WIRE HARNESS (5M)	4	UR FOR QUAD
	6X6-8258A-H0	EXTENSION, WIRE HARNESS (8M)	1	UR FOR SINGLE
	6X6-8258A-H0	EXTENSION, WIRE HARNESS (8M)	2	UR FOR TWIN
	6X6-8258A-H0	EXTENSION, WIRE HARNESS (8M)	3	UR FOR TRIPLE

DIGITAL ELECTRONIC REMOTE CONTROL WIRE HARNESS



Uses to connect between main helm RC and 2nd hlem RC.
(For new digital electronic RC)





Uses to connect between main helm RC and 2nd hlem RC. (Quad RC special)

6X62100-J290

FIG. 29 ELECTRICAL WIRE HARNESS

EF. O. PART NO.	DESCRIPTION	DNC	REMARKS
2 6X6-8258A-H0	EXTENSION, WIRE HARNESS (8M)	4	UR FOR QUAD
6X6-8258A-J0	EXTENSION, WIRE HARNESS: 12.2M	1	UR FOR SINGLE
6X6-8258A-J0	EXTENSION, WIRE HARNESS: 12.2M	2	UR FOR TWIN
6X6-8258A-J0	EXTENSION, WIRE HARNESS: 12.2M	3	UR FOR TRIPLE
6X6-8258A-J0	EXTENSION, WIRE HARNESS: 12.2M	4	UR FOR QUAD
3 6X6–8258A–B1	EXTENSION, WIRE HARNESS (5M)		UR FOR SINGLE
6X6-8258A-B1	EXTENSION, WIRE HARNESS (5M)	2	UR FOR TWIN,QUA
6X6-8258A-B1	EXTENSION, WIRE HARNESS (5M)	3	UR FOR TRIPLE
6X6-8258A-D1	EXTENSION, WIRE HARNESS (8M)	1	UR FOR SINGLE
6X6-8258A-D1	EXTENSION, WIRE HARNESS (8M)	2	UR FOR TWIN,QUA
6X6-8258A-D1	EXTENSION, WIRE HARNESS (8M)		UR FOR TRIPLE
6X6-8258A-F1	EXTENSION, WIRE HARNESS: 12.2M	1	UR FOR SINGLE
6X6-8258A-F1	EXTENSION, WIRE HARNESS: 12.2M	2	UR FOR TWIN,QUA
6X6-8258A-F1	EXTENSION, WIRE HARNESS: 12.2M	3	UR FOR TRIPLE
4 6X6-8258A-R0	EXTENSION, WIRE HARNESS (5M)	1	UR FOR QUAD
6X6-8258A-S0	EXTENSION, WIRE HARNESS (8M)		UR FOR QUAD
6X6-8258A-T0	EXTENSION, WIRE HARNESS: 12.2M	1	UR FOR QUAD
			_
			-






FIG. 30 OPTIONAL PARTS 1

REF. NO.	PART NO.	DESCRIPTION	Ç	DNC DNC				REMARKS
1 6	6X6-82590-A0	WIRE HARNESS ASSY		1				FOR SINGLE
6	6X6-82590-B0	WIRE HARNESS ASSY		1				FOR TWIN
2 7	703–82591–00	BAND		4				FOR SINGLE
7	703–82591–00	BAND		8				FOR TWIN
3 6	6X6-82570-C0	PANEL SWITCH ASSY		1				FOR TWIN,TRIPLE
4 6	5X6-81980-20	.DIODE ASSY		1	- -			
5 6	6X6-82571-60	.PANEL, SWITCH		1				
6 6	6X6-8259E-20	.SWITCH ASSY		1				
				4	_		_	
				1	- -		-	
				_				
_					_ [_		
				Ī			_	




(2S Converter Harness for current Single Switch panel-New control Box)

(2S Converter Harness for current Twin Switch panel-New control Box)



(2S Converter Harness for current Triple Switch panel-New control Box)



6X62100-J310

FIG. 31 OPTIONAL PARTS 2

	. 01 01 110117	TET AITIO E		
REF NO.	PART NO.	DESCRIPTION	DNC	REMARKS
1	6X6-8258A-M0	EXTENSION, WIRE HARNESS	1	FOR SINGLE SUB
2	6X6-8258A-N0	EXTENSION, WIRE HARNESS	1	FOR TWIN SUB
3	6X6-8258A-P0	EXTENSION, WIRE HARNESS	1	FOR TRIPLE SUB
4	6X6-8258A-K0	EXTENSION, WIRE HARNESS	1	UR FOR SINGLE
	6X6-8258A-K0	EXTENSION, WIRE HARNESS	2	UR FOR TWIN
	6X6-8258A-K0	EXTENSION, WIRE HARNESS		UR FOR TRIPLE
5	6X7-82590-30	WIRE HARNESS ASSY	1	FOR 6X7 RC
-			_ _ _ _	+-
			_	
_				
-				+-
				 -




FIG. 32 DIGITAL NETWORK GAUGE 1

	ia. 52 Bianacherwein aacach							
REF NO.	PART NO.	DESCRIPTION		DNC				REMARKS
1	6Y8-8350T-01	TACHOMETER, SQ		1				
2	6Y8-83363-00	.BEZEL, SQUARE		1				
3	6Y8-84383-00	.NUT, RING		1				
4	6Y8-8350S-01	SPEEDOMETER, SQ		1				
5	6Y8-83363-00	.BEZEL, SQUARE		1				
6	6Y8-84383-00	.NUT, RING		1	- -	-	-	
7	6Y8-8350F-01	FL MGT METER, SQ		1				FUEL MANAGEMENT
8	6Y8-83363-00	.BEZEL, SQUARE		1				
9	6Y8-84383-00	.NUT, RING		1				
10	6Y8-83500-01	S&FM METER, SQ		1				SPEED & FUEL
11	6Y8-83363-00	.BEZEL, SQUARE		1	- -	-	-	
12	6Y8-84383-00	.NUT, RING		1				
13	6Y8-8350T-11	TACHOMETER, RD		1				
14	6Y8-84383-00	.NUT, RING		1				
15	6Y8-83500-11	S&FM METER, RD		1				SPEED & FUEL
16	6Y8-84383-00	.NUT, RING		- ₁	- -	-		
17	6Y8-83514-00	PLATE, FITTING		1				UN
					- -	-		
					- -	-	ļ _	
						-1		<u> </u>




FIG. 33 DIGITAL NETWORK GAUGE 2

REF NO.	PART NO.	DESCRIPTION	DNC	REMARKS
1	6Y8-8356N-01	LEAD, FUEL TANK & GPS SENDER	1	
2	6Y8-81920-01	MULTI HUB ASSY	1	UN
3	6Y8-85371-01	END OF LINE RESISTER	1	
4	6Y8-81920-11	IN-LINE HUB ASSY	1	
5	6Y8-82582-01	CAP 1 (2PIN)	1	UN
- - 6	6Y8-82582-11	CAP 1 (4PIN)	-1 - -	
7	6Y8-82553-01	1FT MAIN BUS	1	UR
	6Y8-82553-11	15FT MAIN BUS	1	UR
	6Y8-82553-21	20FT MAIN BUS	1	UR
	6Y8-82553-31	25FT MAIN BUS	1	UR
	6Y8-82553-41	30FT MAIN BUS	-1 - -	+- -uR
	6Y8-82553-50	10FT MAIN BUS	1	UR
8	6Y8-82521-01	1FT PIGTAIL BUS	1	UR
	6Y8-82521-11	2FT PIGTAIL BUS	1	UR
	6Y8-82521-21	3FT PIGTAIL BUS	1	UR
	6Y8-82521-31	6FT PIGTAIL BUS	-1 - -	
	6Y8-82521-41	9FT PIGTAIL BUS	1	UR
	6Y8-82521-51	12FT PIGTAIL BUS	1	UR
9	6Y8-83553-01	8FT POWER WIRE	1	
10	6G1-82151-00	.FUSE (10A)	1	
11	6Y8-82570-02	PANEL SW., TWIN	-1 - -	+-
12	6Y8-82571-01	.PLATE, PANEL SWITCH	1	
13	6Y8-82510-02	.MAIN SWITCH ASSY	2	
14	676-82577-00	CAP, KEY	1	
15	6K1-82575-00	ENGINE STOP SWITCH ASSY	1	
16	682-82556-00	LANYARD, STOP SWITCH		
17	6R5-83383-00	.BUZZER	2	






FIG. 33 DIGITAL NETWORK GAUGE 2

REF NO.	PART NO.	DESCRIPTION		DNC				REMARKS
18	68V-81950-00	.RELAY ASSY		2				
19	6Y8-82507-00	LEAD, IGNITION SWITCH RELAY		1				
20	64D-82581-00	.STAY, CORD CLAMP		2				
21	97303-05012	.BOLT		2				
22	92903-05100	.WASHER, SPRING		2				
23	95303-05700	.NUT		2	- -	-	 	
24	6K1-82571-02	PLATE, PANEL SWITCH		1				
						-	 	
				_	_	_	_	
						-	T -	






6Y82110-E030

FIG. 34 DIGITAL NETWORK GAUGE 3

rid. 34 Digital Network GAUGE 3							
REF. NO. P	ART NO.	DESCRIPTION	DNC				REMARKS
1 6Y8-836	688–01	TRANSOM MOUNT TRIDUCER	1				
2 6Y8-836	688–11	PLASTIC THRU-HULL TRIDUCER	1	I			PLASTIC BODY
3 6Y8-836	688–20	BRONZE THRU-HULL TRIDUCER	1	ı			BRONZE BODY
4 6Y8-825	521–01	1FT PIGTAIL BUS	1	ı			UR
6Y8-825	521–11	2FT PIGTAIL BUS	1	I			UR
6Y8-825	521–21	3FT PIGTAIL BUS	· - ₁	-		- + -	UR
6Y8-825	521–31	6FT PIGTAIL BUS	1	I			UR
6Y8-825	521–41	9FT PIGTAIL BUS	1	ı			UR
6Y8-825	521–51	12FT PIGTAIL BUS	1	I			UR
			-	-		-	-
				↓ _		_	_
]_		Ī	
			-	 		- † :	-
			•				

Cooling water pressure sensor

Part No.	Remarks
60V-8A4L0-12	Fuel injected F30-F115, HPDI




601M10M-J150

FIG. 35 DIGITAL NETWORK GAUGE 4

- 10	FIG. 33 DIGITAL NETWORK GAUGE 4							
REF NO.	PART NO.	DESCRIPTION	DNC				REMARKS	
1	60V-8A4L0-12	SENSOR, MODULE	1					
2	60V-8366D-00	.ADAPTOR, INPUT	1					
3	95895-06025	.BOLT, FLANGE	1					
4	60V-83667-00	.SENDER, WATER PRESSURE	1					
5	90430-14115	.GASKET	1					
6	90445-07018		1	-	-	- † -		
7	90447–07015	.HOSE, COVER (L: 1300MM)	1					
8	90465-11M10	.CLAMP	4					
9	6AW-8366B-00	.SENSOR, WATER PRESSURE	1					
10	60V-8257V-00	.PLATE, CONNECTOR	1					
11	97095–06016	BOLT	1	-	-	- † -		
12	92995-06600	.WASHER	1					
13	90464-09021	.CLAMP	1					
14	90109-06M81	.BOLT	1					
					-	- † -		
					-	- † -		
				-		-		

Cooling water pressure sensor

Part No.	Remarks
69J-8A4L0-11	F150-F250




601M10M-H160

FIG. 36 DIGITAL NETWORK GAUGE 5

PIG. 30 DIGITAL NETWORK GAUGE 5							
REF. NO. PART NO.	DESCRIPTION	DNC	REMARKS				
1 69J-8A4L0-11	WATER PRESSURE SENSOR KIT	1					
2 6AW-8366B-00	.SENSOR, WATER PRESSURE	1					
3 69J-8366C-00	.ADAPTOR, INPUT	1					
4 63P-8366C-00	.ADAPTOR, INPUT	1					
5 90430–14115	.GASKET	1					
			-				
			-				
			-				
			-				

Speed sensor

Part No.	Remarks
60V-8A4L1-11	Fuel injected F30-F250, HPDI




6X62100-J370

FIG. 37 DIGITAL NETWORK GAUGE 6

REF. NO.	PART NO.	DESCRIPTION		DNC				REMARKS
1	60V-8A4L1-11	SENSOR, MODULE 1		1				
2	6AW-8366B-00	.SENSOR, WATER PRESSURE		1				
3	60V-8366D-00	.ADAPTOR, INPUT		1				
4	90109-06M81	.BOLT		1				
5	90465-11M10	.CLAMP		2				
6	90445–07017	.HOSE (L: 550MM)		1	- -	-	† -	
7	90447-07013	.HOSE, COVER (L: 700MM)		1				
8	60V-42629-00	.SEAL		1				
9	97095-06016	.BOLT		1				
10	92995-06600	.WASHER		1				

Speed sensor


Part No.	Remarks
6AW-8A4L1-01	F300/F350 * Additional transom pitot tube (688-83556-01) and pressure tube(688-83557-00) required.



601M10M-H180

FIG. 38 DIGITAL NETWORK GAUGE 7

FIG. 36 DIGITAL NETWORK GAUGE I												
REF NO.	PART NO.	DESCRIPTION	DNC				REMARKS					
1	6AW-8A4L1-01	SENSOR, MODULE 1	1									
2	90465-06M86	.CLAMP	2									
3	90465-14M66	.CLAMP	2									
4	90447–07015	.HOSE, COVER (L: 1300MM)	1									
5	90445-07018	.HOSE (L1400)	1									
6	97095–06016	.BOLT	1	- -	-	 						
7	92995-06600	.WASHER	1									
8	60V-8366D-00	.ADAPTOR, INPUT	1									
9	6AW-8366B-00	.SENSOR, WATER PRESSURE	1									
				- -	-	 						
				- -	-	 						
				- -	-	ļ _						
			L _	_	_	<u> </u>						






FIG. 39 COMMAND LINK PLUS

REF NO.	PART NO.	DESCRIPTION	DNC				REMARKS
1	6Y9-83710-00	MULTI DISPLAY ASSY	1				UN
2	6Y9-8356N-00	WIRE, LEAD	1				FOR GPS
3	6Y9-8356N-10	WIRE, LEAD	1				FOR TANKS
4	6Y9-83553-00	WIRE, LEAD	1				UR 1 STATION
	6Y9-83553-10	WIRE, LEAD	1				UR 2 STATION
- <u>-</u> 5	6Y9-83553-40	WIRE, LEAD	 1	- -		 	UN FOR MULTI DISPLAY
6	6Y9-83553-50	WIRE, LEAD	1				UN FOR INTERFACE UNI
7	6Y9-83553-60	WIRE, LEAD	1				FOR SENSOR ASSY
8	6Y9-83688-00	SENSOR ASSY	1				
9	6Y9-8A2D0-00	INTERFACE UNIT	1				GATEWAY
10	6Y9-8A2D0-10	INTERFACE UNIT	 1	- -	-	+ -	UN ANALOGE GAUGE
11	6Y9-83512-00	.COVER, FRONT	1				
			 	- -		 	
			 	_	l	ļ _	
			 		<u>.</u>	<u> </u>	

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
60V-42629-00	37 - 8	704–48156–00	11 – 48	703–48198–00	9 - 33	6X6-48212-00	11 – 30	6X6-48225-00	11 – 25	6X6-48245-01	10 - 75
6X6-44191-00	9 - 56		12 – 47		10 - 39		12 – 29		12 – 25		11 – 86
	10 - 63	6X6-48158-00	9 - 38		11 – 39	6X7-48212-00	14 – 19	6X7-48225-00	14 – 15		12 – 76
	11 - 63		10 - 44		12 – 38	6X6-48213-00	9 - 43	703-48227-00	14 – 8		14 – 28
	12 – 57		11 – 44		14 – 38		10 - 51	6X6-48228-00	9 – 44	6X6-48264-00	9 - 39
6X7-44191-00	14 – 16		12 – 43	6X6-481A0-01	9 - 24		11 - 51		10 - 52		10 - 45
6X6-48118-00	9 - 35	01/0 4040= 00	14 – 33	01/= 10110 01	10 – 29	01/= 4004= 40	12 - 50		11 - 52		11 – 45
	10 - 41	6X6-48167-00	9 – 16	6X7-481A0-01	14 – 18	6X7-48215-10	14 – 17	01/7 40000 00	12 - 51		12 – 44
	11 - 41	6X7-48167-00	14 - 14	6X6-481A0-11	11 – 29	6X6-48215-30	9 - 13	6X7-48228-00	14 – 25	CVC 40007 00	14 - 30
	12 - 40 14 - 40	6X6-48167-10	10 - 17 11 - 17	CVC 401A0 01	12 – 28	6X6-48215-40 6X6-48215-50	10 – 15 11 – 15	6X7-48233-00 6X6-48233-01	14 – 23 9 – 28	6X6-48267-00	9 - 37 10 - 43
6X7-48119-00	14 – 40 14 – 12		11 - 17	6X6-481A0-21	10 – 71 11 – 73		11 - 15	000-48233-01	9 – 28 10 – 34		10 - 43
		6V7 40167 10	12 - 17 14 - 13	6X6-481A0-31		6X6-48215-70					
6X6-48119-04	9 – 12 10 – 13	6X7-48167-10 6X6-48167-20	14 - 13 10 - 18	CVC 4000E 00	12 - 64 1 - 1	6X6-48216-00	9 - 14 10 - 16		11 – 34 12 – 33		12 – 42 14 – 31
6X6-48119-10	10 - 13	000-48107-20	10 - 18	6X6-48205-30	2 - 1	6X6-48216-10	10 - 16	6X6-48234-00	9 – 36	704-48283-00	14 - 31
	12 – 13		12 – 18		9 - 1	6X6-48216-20	12 - 16	000-40234-00	10 - 42	704-40203-00	11 - 49
6X6-48127-00	9 – 59	6X6-48167-50	9 – 17	6X6-48205-40	1 – 1	6X6-48219-00	9 – 18		10 - 42		12 - 48
0/0-40127-00	9 – 59 10 – 66	6X6-48167-60	10 - 19	0/10-40/200-40	2 - 1	6X6-48219-10	10 - 20		12 - 41	701-48287-00	14 - 66
	11 - 66	070-40107-00	11 - 19		9 - 1	070-40219-10	11 - 20		14 – 37	704-48287-00	9 - 40
	12 - 60		12 – 19	6X6-48205-50	1 - 1		12 – 20	6X6-48236-00	9 – 31	704-40207-00	9 – 40 10 – 46
6X7-48127-00	11 - 81	6X6-48171-00	9 - 9	670-46203-30	2 - 1	6X6-48219-20	10 - 21	0/10-40230-00	10 - 37		11 - 46
0.77-40127-00	12 – 71	070-40171-00	10 - 10		9 - 1	070-40219-20	11 - 21				12 – 45
	14 – 43		11 - 10	6X7-48206-10	8 - 1		12 – 21		12 – 36	- 37 2 - 36 3 - 34 6X6-81145-00	14 - 32
EL8-48127-00	9 – 11		12 – 10	0/1/ 40200 10	14 – 1	6X6-48221-00	9 - 3		14 – 34	6X6-81145-00	9 – 41
LLO 40127 00	10 - 12		14 - 9	6X6-48207-30	3 - 1	070 40221 00	10 - 3	6X6-48237-00	9 – 30	0//0 01140 00	10 - 69
	11 - 12	6X6-48176-00	9 – 21	0/10 40207 00	4 - 1		11 - 3	070 40207 00	10 – 36		11 - 69
	12 - 12	6X6-48176-10	10 - 24		10 - 1		12 - 3		11 – 36		12 - 63
	14 - 44	0/10 101/0 10	11 - 24	6X6-48207-40	3 - 1	6X7-48221-00	14 - 3		12 – 35	6X6-81146-00	9 - 61
6X0-48128-00	11 - 82		12 - 24	0,10 10201 10	4 – 1	6X6-48222-00	9 – 4		14 - 35	0,10 01110 00	10 - 68
0.10 10.20 00	12 - 72	6X7-48176-10	14 - 68		10 - 1	0710 10222 00	10 - 4	6X6-48238-00	9 – 29		11 – 68
	14 - 60	6X6-48176-50	9 – 57	6X6-48207-50	3 - 1		11 - 4	0710 10200 00	10 - 35		12 - 62
6X6-48128-00	9 - 60		10 - 64		4 – 1		12 – 4		11 - 35	6Y8-81920-01	33 - 2
	10 - 67		11 - 64		10 - 1	6X7-48222-00	14 – 4		12 - 34	6Y8-81920-11	33 - 4
	11 - 67		12 - 58	6X6-48208-40	5 – 1	6X6-48222-10	10 - 6		14 - 36	68V-81950-00	18 – 8
	12 - 61	6X6-48176-60	9 - 58		6 - 1		11 – 6	6X6-48241-00	9 - 64		21 - 11
	14 - 11		10 - 65		11 – 1		12 - 6		10 - 74		25 - 13
6X7-48128-00	14 - 67		11 - 65	6X6-48208-50	5 – 1	6X7-48223-00	14 – 6		11 - 85		25 - 26
6X6-48129-00	9 - 55		12 - 59		6 - 1	6X6-48224-00	9 – 5		12 - 75		26 - 13
	10 - 62	6X6-48189-00	9 - 32		11 - 1		10 - 5		14 - 29		26 - 26
	11 - 62		10 - 38	6X6-48209-00	7 – 1		11 – 5	6X7-48242-00	14 - 24		33 - 18
	12 - 56		11 – 38		12 – 1		12 – 5	6X6-48242-01	9 - 27	704-81950-10	9 - 62
6X6-48144-00	9 - 54		12 - 37	6X6-48209-10	7 – 1	6X7-48224-00	14 – 5		10 - 32		10 - 72
6X6-48144-10	9 - 26	6X7-48189-00	14 - 20		12 – 1	6X6-48224-10	9 - 6		11 – 32		11 – 83
	10 - 31	6X6-48193-00	9 - 34	6X6-48211-10	11 – 75		10 - 7		12 – 31		12 – 73
	11 – 31		10 - 40		12 - 65		11 – 7	6X6-48242-11	10 - 33		14 – 53
	12 - 30		11 - 40		14 – 54		12 – 7		11 – 33	6X6-81980-00	19 – 6
6X0-48156-00	14 - 65		12 – 39	6X6-48212-00	9 - 25	6X7-48224-10	14 – 7		12 – 32		20 – 5
704-48156-00	10 – 48		14 - 39		10 - 30	6X6-48225-00	10 - 25	6X6-48245-01	9 - 65		22 – 6

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
6X6-81980-00	23 - 5	6K1-82532-00	26 - 19	64D-82570-20	28 - 1	6X6-82570-T0	26 - 1	6Y8-82582-01	33 - 5	6X6-8258A-30	29 – 1
	27 – 5		28 - 6	6X6-82570-30	2 - 2	6X6-82570-U0	7 – 5	6Y8-82582-11	33 - 6		29 – 1
	27 - 10	6X6-82540-00	9 - 63		16 – 1		26 - 14	6X6-82582-40	9 - 52		29 – 1
6X6-81980-10	24 – 3		10 - 73	6X6-82570-40	4 – 2	6X6-82570-V0	7 – 6		10 - 60	6X6-8258A-40	29 – 1
6X6-81980-20	30 – 4		11 – 84		19 – 1		26 – 27		11 – 60		29 – 1
6G1-82151-00	33 - 10		12 – 74	6X6-82570-50	6 - 2		27 – 11		13 – 4		29 – 1
6X5-82507-00	21 - 10		14 – 27		22 – 1	64D-82571-00	25 – 2		13 – 9		29 – 1
6X6-82507-00	25 – 12	6X6-82540-10	10 – 78	6X6-82570-60	4 - 3		25 – 15	6X6-82582-60	9 - 51	6X6-8258A-B1	29 – 3
6Y8-82507-00	18 - 9		11 - 89	000 00570 70	19 – 7		26 - 2		10 - 59		29 - 3
6X6-82507-10	33 – 19 25 – 25	6V6 00E4E 00	12 - 79 9 - 66	6X6-82570-70	6 - 3 22 - 7		26 – 15 28 – 2		11 – 59 13 – 3	CVC COECA D1	29 - 3 29 - 3
6X6-82507-10	25 – 25 26 – 12	6X6-82545-00	9 – 66 10 – 76	6X6-82570-80	22 – 7 1 – 3	6X5-82571-00	28 – 2 21 – 6		13 – 3 13 – 8	6X6-8258A-D1	29 - 3
6X6-82507-20	26 – 12 26 – 25		10 - 76	676-62570-60	2 - 3	6Y8-82571-00	18 - 2	6X6-82582-A0	13 - 8		29 - 3
6X6-82510-00	26 – 25 16 – 2		12 – 77		2 - 3 17 - 1	010-023/1-01	33 – 12	6X6-82582-B0	9 - 53	6X6-8258A-F1	29 - 3
6X5-82510-00	21 - 2	6X7-82545-00	14 – 26	6X6-82570-90	1 - 4	6K1-82571-02	33 - 12	070-02302-00	10 - 61	0A0-0230A-1 1	29 - 3
6R5-82510-02	15 – 4	6Y8-82553-01	33 - 7	070-02370-30	2 - 4	704-82571-02	15 – 2		11 - 61		29 - 3
6Y8-82510-02	18 – 3	6Y8-82553-11	33 - 7		3 - 4	6K1-82575-00	18 - 5		13 - 5	6X6-8258A-G0	29 - 2
010 02310 02	33 – 13	6Y8-82553-21	33 - 7		4 - 5	0111 02373 00	33 – 15		13 – 10	070 02507 G0	29 - 2
6X6-82510-10	19 - 2	6Y8-82553-31	33 - 7		5 – 4	6X5-82575-00	21 - 4	6X6-82584-00	11 – 79		29 - 2
64D-82510-20	25 – 4	6Y8-82553-41	33 - 7		6 - 5	6X7-82575-00	14 – 45	07.0 02001 00	12 – 69		29 - 2
	25 - 17	6Y8-82553-50	33 - 7		24 – 1	688-82575-01	15 - 6		14 - 58	6X6-8258A-H0	29 - 2
	26 - 4	682-82556-00	15 - 7	6X6-82570-B0	1 – 5		16 - 3	6X6-82585-20	9 - 50		29 – 2
	26 - 17		16 – 4		2 - 5	6X6-82575-10	19 – 3		10 - 58		29 – 2
	28 – 4		18 – 6		3 - 5		22 - 3		11 - 58		29 – 2
6X6-82510-20	22 - 2		19 – 4		4 - 6	6X6-82575-30	26 - 28		13 - 2	6X6-8258A-J0	29 – 2
6Y8-82521-01	33 – 8		21 – 5		5 – 5		27 – 12		13 – 7		29 – 2
	34 – 4		22 – 4		6 - 6	676-82577-00	15 – 5		14 – 47		29 – 2
6Y8-82521-11	33 – 8		33 – 16		24 – 2		18 – 4	6X6-82585-40	14 – 50		29 – 2
	34 – 4	6X6-82556-00	26 – 29	6X6-82570-C0	30 – 3		21 – 3	6X6-82585-60	14 – 49	6X6-8258A-K0	31 – 4
6Y8-82521-21	33 – 8		27 – 13	6X6-82570-E0	3 - 3		33 - 14	64D-82588-00	25 – 3		31 – 4
	34 – 4	6X6-82563-00	9 – 2		4 - 4	703-82577-00	25 – 5		25 – 16		31 – 4
6Y8-82521-31	33 - 8		10 - 2	01/0 00570 50	20 – 1		25 – 18		26 – 3	6X6-8258A-L0	18 – 14
0)/0 00501 11	34 – 4		11 - 2	6X6-82570-F0	5 - 3		26 – 5		26 – 16		21 – 12
6Y8-82521-41	33 - 8	0.77 0.0500 0.0	12 - 2		6 - 4		26 – 18	ODE 00500 04	28 - 3	000 00504 140	26 – 31
6Y8-82521-51	34 – 4 33 – 8	6X7-82563-00 6X6-82563-40	14 – 2 10 – 26	6X6-82570-J0	23 – 1 7 – 7	60V-8257V-00	28 - 5 35 - 10	6R5-82588-01 6X6-8258A-00	15 – 3 29 – 1	6X6-8258A-M0 6X6-8258A-N0	31 – 1 31 – 2
010-02021-01	33 - 8	0.00-82303-40	10 - 26	676-82370-30	7 – 7 27 – 1	64D-82581-00	15 – 10 15 – 8	6X6-8238A-00	29 – 1 29 – 1	6X6-8258A-NU	31 - 2
6X6-8252S-00	11 – 78	6X6-82563-50	10 - 70	6X6-82570-K0	7 - 8	040-02301-00	18 - 10		29 - 1	6X6-8258A-R0	29 – 4
070-02323-00	12 – 68	070-02303-30	11 - 70	0X0-02370-N0	27 - 6		25 - 7		29 - 1	6X6-8258A-S0	29 - 4
	14 - 57	6X6-82563-60	11 - 70	6X6-82570-L0	7 - 9		25 – 7 25 – 20	6X6-8258A-10	29 - 1	6X6-8258A-T0	29 - 4
6X6-8252V-00	9 – 67	6X5-82570-01	5 - 2	0X0-02370-L0	26 - 30		26 - 7	0X0-0230A-10	29 - 1	6X6-8258A-U0	26 - 32
070 0202 00	10 - 77	0/10 0/2070 01	21 - 1		27 – 14		26 – 20		29 – 1	6X7-82590-20	14 - 51
	11 – 88	6Y8-82570-02	3 - 2	6X6-82570-N0	13 - 11		28 - 7		29 - 1	6X7-82590-20	31 - 5
	12 - 78	2.0 020.0 02	18 – 1	6X6-82570-R0	7 – 2		33 - 20	6X6-8258A-20	29 – 1	6X7-82590-40	14 – 46
	14 - 42		33 – 11		25 – 1	6X5-82581-00	21 – 8	<u></u>	29 – 1	6X6-82590-A0	9 – 49
6K1-82532-00	25 – 6	6R5-82570-05	1 - 2	6X6-82570-S0	7 - 3	6X6-82581-00	11 - 80		29 – 1		30 - 1
	25 – 19		15 – 1		25 – 14		12 - 70		29 – 1	6X6-82590-B0	10 - 57
	26 - 6	64D-82570-20	8 - 2	6X6-82570-T0	7 – 4		14 - 59	6X6-8258A-30	29 – 1		30 - 1

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
6X6-82590-C0	11 – 57	6X5-83383-00	21 - 7	6X6-84301-23	11 - 14	92990-05200	11 – 23	98580-04010	9 - 22		
6X6-82590-D0	9 - 49	688-83383-11	25 - 11	6X6-84301-30	12 - 14		12 - 23		10 - 27		
6X6-82590-E0	10 - 57		25 - 24	6Y8-84383-00	32 - 3		14 - 63		11 – 27		
6X6-82590-F0	11 - 57		26 - 11		32 - 6	92990-05300	9 - 8		12 - 26		
6X6-82590-G0	9 - 49		26 - 24		32 – 9		10 - 9	98580-05014	9 – 7		
6X6-82590-H0	10 – 57		28 – 11		32 - 12		11 – 9		10 – 8		
6X6-82590-J0	13 – 1	703-83383-A0	16 – 5		32 – 14		12 – 9		11 – 8		
6X6-82590-K0	13 – 6		17 – 3		32 – 16	92990-08600	9 - 10		12 – 8		
6X6-82590-L0	13 – 1		19 – 5	6Y8-85371-01	33 – 3		10 - 11		14 - 62		
6X6-82590-M0	13 – 6		20 – 3	6X6-85557-00	11 – 76		11 - 11	98580-05025	10 - 47		
6X6-82591-00	11 – 77		22 – 5		12 – 66		12 – 11		11 – 47		
	12 – 67		23 – 3	-14	14 – 55		14 - 10		12 – 46		
	14 – 56		27 – 3	6X6-85590-20	9 – 45	92995–06600	35 – 12		14 – 61		
703-82591-00	9 - 46	01/0 00=00 0/	27 – 8		10 - 53		37 – 10	98580-05060	9 - 47		
	10 – 54	6Y8-83500-01	32 – 10		11 - 53	00000 05010	38 – 7		10 - 55		
	11 – 54	6Y8-83500-11	32 – 15		12 - 52	92D80-05016	9 – 23		11 - 55		
	12 – 53	6Y8-8350F-01	32 - 7	CVO 040D0 00	14 – 52		10 – 28	00700 05040	12 - 54		
	14 – 41	6Y8-8350S-01	32 – 4	6Y9-8A2D0-00	39 – 9		11 – 28	98780-05010	11 – 74		
	30 - 2 30 - 2	6Y8-8350T-01 6Y8-8350T-11	32 – 1 32 – 13	6Y9-8A2D0-10 69J-8A4L0-11	39 – 10	05000 05700	12 – 27	98780–05014	9 - 42 10 - 50		
6X6-8259E-00	30 – 2 9 – 19	6Y8-83514-00	32 - 13 32 - 17	60V-8A4L0-11	36 – 1 35 – 1	95303–05700	15 – 11 18 – 13		10 - 50		
0A0-0239E-00	10 - 22	6Y9-83553-00	39 - 4	6AW-8A4L1-01	38 – 1		25 – 10		12 - 49		
	11 - 22	6Y8-83553-01	33 - 9	60V-8A4L1-11	37 - 1		25 - 10	98780-06035	14 - 64		
	12 – 22	6Y9-83553-10	39 – 4	90109–06M81	35 – 14		26 - 10	30700-00033	14 - 04		
6X7-8259E-00	14 – 21	6Y9-83553-40	39 - 5	30103-00IVIO1	37 – 4		26 – 23				
6X6-8259E-20	17 - 2	6Y9-83553-50	39 – 6	90430-14115	35 - 5		28 - 10				
0710 0E00E E0	19 - 8	6Y9-83553-60	39 – 7	00100 11110	36 - 5		33 - 23				
	20 - 2	6Y9-8356N-00	39 – 2	90445-07017	37 – 6	95380-05600	9 – 48				
	22 - 8	6Y8-8356N-01	33 – 1	90445-07018	35 – 6		10 - 56				
	23 - 2	6Y9-8356N-10	39 – 3		38 - 5		11 - 56				
	27 – 2	60V-83667-00	35 – 4	90447-07013	37 – 7		12 - 55				
	27 – 7	6AW-8366B-00	35 – 9	90447-07015	35 – 7	95895-06025	35 – 3				
6X6-8259F-10	11 - 72		36 - 2		38 - 4	97095-05012	25 – 8				
6X6-82716-00	19 – 9		37 – 2	90464-09021	35 - 13		25 - 21				
6X6-82716-10	22 – 9		38 – 9	90465-06M86	38 – 2		26 – 8				
6X6-82716-20	17 – 4	63P-8366C-00	36 – 4	90465-11M10	35 – 8		26 – 21				
6X6-82716-40	20 – 4	69J-8366C-00	36 – 3		37 – 5	97095–06016	35 – 11				
	27 – 4	60V-8366D-00	35 – 2	90465-14M66	38 – 3		37 – 9				
	27 – 9		37 – 3	92903-05100	15 – 10		38 – 6				
6X6-82716-50	23 – 4		38 - 8		18 – 12	97303-05012	15 – 9				
6Y8-83363-00	32 – 2	6Y9-83688-00	39 – 8		25 – 9		18 – 11				
	32 – 5	6Y8-83688-01	34 – 1		25 – 22		28 - 8				
	32 - 8	6Y8-83688-11	34 – 2		26 – 9	07700 00000	33 – 21				
CDE 00000 00	32 – 11	6Y8-83688-20	34 – 3		26 – 22	97780-06230	14 – 64				
6R5-83383-00	15 – 12	6Y9-83710-00	39 – 1		28 - 9	97780–50145	9 – 47				
	18 – 7	6X6-84301-00	9 – 15	02000 05200	33 - 22		10 - 55				
6X4-83383-00	33 – 17 21 – 9	6X7-84301-00 6X6-84301-13	14 - 22 10 - 14	92990-05200	9 - 20 10 - 23		11 – 55 12 – 54				
	Z 1 - 3	0/10 0+00 1-10	10 - 14		10 - 23		12 - 54				